

JJ50QT-21 SPARE PARTS CATALOGUE (FRONT DISC, REAE DRUM)



REF NO.	CHINESE NAME	ENGLISH NAME	PICTURE
JJ50QT-21-01	挡风罩	WIND SCREEN COVER	
JJ50QT-21-02	前面板	FRONT PANEL	
JJ50QT-21-03	前挡泥板前部	FENDER FRONT COVER	
JJ50QT-21-04	前挡泥板后部	FENDER REAR COVER	
JJ50QT-21-05	左右边盖	COVER L&R BODY SIDE	
JJ50QT-21-06	左右护条	L&R LATH	

JJ50QT-21-07	杂物箱前罩	COVER CENTER	
JJ50QT-21-08	后罩	REAR COVER CENTER	
JJ50QT-21-09	装饰板镀铬块	COVER LITTLE CENTER	
JJ50QT-21-10	左右灯镀铬块	LIGHT AND RIGHT CHROMIC PLATE	
JJ50QT-21-11	前大灯镀铬块	FRONT LIGHT CHROMIC PLATE	
JJ50QT-21-12	前大板镀铬块	FRONT COVER CHROMIC PLATE	
JJ50QT-21-13	前轮板镀铬块	FRONT FENDRED CHROMIC PLATE	
JJ50QT-21-14	后中心嵌条(油箱口盖板)	MOLD RR CENTER	
JJ50QT-21-15	检修口罩	TESTING COVER	
JJ50QT-21-16	手把后盖(仪表壳)	COVER HANDLE RR	
JJ50QT-21-17	前置物箱	FRONT SUNDRIES BOX	

JJ50QT-21-18	前泥板支架	FR MUD DEFENDER STAY	
JJ50QT-21-19	后轮挡泥板	RR. FENDER	
JJ50QT-21-20	后泥板支架	REAR MUD DEFENDER STAY	
JJ50QT-21-21	杂物箱	BOX LUGGAGE	
JJ50QT-21-22	杂物箱内盖	COVER ASSY CARB MAINT	
JJ50QT-21-23	脚踏板	FOOTREST	
JJ50QT-21-24	脚踏垫	MAT FLOOR	
JJ50QT-21-25	车架挡泥板	FOOTREST	
JJ50QT-21-26	车架号码盖	LID LEG SHIELD	
JJ50QT-21-27	电瓶盖	COVER BATTERY	
JJ50QT-21-28	仪表	SPEEDOMETER	
JJ50QT-21-29	前大灯	FR. HEADLIGHT	
JJ50QT-21-30	前转向灯	FR/RR, TURNING LIGHT	
JJ50QT-21-31	后尾灯	TAIL LIGHT ASSY	

JJ50QT-21-32	后转向灯	WINKER ASSY	
JJ50QT-21-33	左右前反射片	L/R FR REFLEX REFLECTOR	
JJ50QT-21-34	后反射片	REFLEX REFLECTOR RR	
JJ50QT-21-35	锁总成	KEY SET	
JJ50QT-21-36	把手套	HANDLE	
JJ50QT-21-37	节流管固定座	HOUSING THROT	
JJ50QT-21-38	后视镜	MIRROR ASSY	
JJ50QT-21-39	汤浅电瓶	YUSAS BATTERY 12N7E-B	
JJ50QT-21-40	限速点火器	limit CDI ASSEMBLY	
JJ50QT-21-41	继电器	RELAY	
JJ50QT-21-42	电阻	RESISTANCE	
JJ50QT-21-43	整流器	REG REC COMP	
JJ50QT-21-44	高压包	IGNITION COIL ASSEMBLY	
JJ50QT-21-45	闪光器	SINGING SPARKING RELAY	
JJ50QT-21-46	喇叭	HORN	

JJ50QT-21-47	前碟刹总成	SUB HARNESS SET FR M/C ASSY	
JJ50QT-21-48	左刹车握把	LEVER L STRG HANDLE	
JJ50QT-21-49	后刹车导线	CABLE COMP RR BRK	
JJ50QT-21-50	座垫锁拉线	CABLE SEAT LOCK	
JJ50QT-21-51	里程线	SPEED CABLE	
JJ50QT-21-52	节流导线	CABLE COMP THROT	
JJ50QT-21-53	电缆	MAIN WIRESS	
JJ50QT-21-54	空滤器	AIR CLEANER ASSEMBLY	
JJ50QT-21-55	滤芯	ELEVENT COMP AIR CLEANER	
JJ50QT-21-56	消声器	MUFFLER BARREL	
JJ50QT-21-57	消声器固定环	STAY MUFFLER	
JJ50QT-21-58	消声器固定环橡皮	STAY MUFFLER RUBBER	
JJ50QT-21-59	前轮胎	FRONT TIRE	
JJ50QT-21-60	后轮胎	REAR TIRE	

JJ50QT-21-61	车架	MAIN FRAME	
JJ50QT-21-62	方向把	STEERING HANDLE	
JJ50QT-21-63	转向杆	STEM COMP STRG	
JJ50QT-21-64	钢碗总成	BEARING AND BALL ASSY	
JJ50QT-21-65	三角板	SET SQUARE	
JJ50QT-21-66	吊架	SWING BRACKET	
JJ50QT-21-67	吊架橡皮	RUBBER ENG HANGER	
JJ50QT-21-68	单撑	SIDE STAND	
JJ50QT-21-69	侧支架回位板	SIDE STAND BACK BOARD	
JJ50QT-21-70	单撑弹簧	SPRING, SIDE STAND	
JJ50QT-21-71	双撑	MAIN STAND	
JJ50QT-21-72	双撑回位缓冲橡皮	RUBBER, MAIN STAND	
JJ50QT-21-73	双撑弹簧	SPRING, MAIN STAND	
JJ50QT-21-74	前减震	FR, BAMPER ASSY	
JJ50QT-21-75	后减震	RR, BAMPER ASSY	
JJ50QT-21-76	前轮钢圈	RIM OF FRONT WHEEL	

JJ50QT-21-77	转速器	COUNTER	
JJ50QT-21-78	前碟刹盘	DISK FR BRAKE	
JJ50QT-21-79	后轮钢圈	RIM OF REAR WHEEL	
JJ50QT-21-80	后刹车蹄块	SHOE COMP RR BRAKE	
JJ50QT-21-81	载物架	REAR TAIL STAND	
JJ50QT-21-82	后牌照支架	BRACKET, RR. LICENSE	
JJ50QT-21-83	油箱	FUEL TANK	
JJ50QT-21-84	油箱支架	STAY SEALER	
JJ50QT-21-85	油管	TUBE FUEL ASSY	
JJ50QT-21-86	传感器	FUEL SENSOR ASSY	
JJ50QT-21-87	油箱口盖	FUEL TANK COVER	
JJ50QT-21-88	坐垫	SEAT SET	
JJ50QT-21-89	全套螺丝	ALL THE BOLT SETS	
JJ50QT-21-90	随车工具	TOOLS	

